



Nr : 2009/2.3/16

Data: 27.3.09

---

## **HMI: WinCC Flexible**

---

### **Rilascio di WinCC flexible 2008 SP1**

Il Service Pack 1 per SIMATIC WinCC flexible 2008 è rilasciato per la consegna (incl. Micro, ASIA, CINA).

Il Service Pack 1 può essere scaricato gratuitamente da Internet (ID: [34778772](http://34778772)). I clienti con Software Update Service riceveranno un CD contenente il software automaticamente.

Nel Service Pack 1 vi sono alcune novità funzionali sia per la parte engineering che per la parte runtime. Possibilità, ad esempio, di importare ed esportare liste di testo su base CSV, possibilità di trasferire i progetti in modo indiretto per i pannelli con la nuova funzione "Pack&Go", espansione delle funzionalità nell'opzione Audit ed inoltre il supporto per Wondows Vista Service Pack 1.

Attenzione alla compatibilità con gli altri prodotti SIMATIC

- STEP 7 V5.4 SP3
- STEP 7 V5.4 SP4
- SIMATIC NET CD 2007 (V7.0)
- SIMATIC Logon V1.4 SP1
- SIMOTION SCOUT V4.1 SP1

Nuove compatibilità con il Service Pack 1 di WinCC flexible 2008:

- SIMATIC NET CD 2008 (V7.1)
- SIMOTION SCOUT V4.1 SP2
- SIMATIC WinAC MP 2008 (V4.1.1)

Per scaricare il Service Pack 1:

<http://support.automation.siemens.com/WW/llisapi.dll?func=cslib.csinfo&objId=34778772&objAction=csOpen&nodeid0=1650>



**Codici di Ordinazione Software e Starter kit (sono rimasti invariati rispetto alla versione 2008):**

Prodotto	Codice
<b>Engineering software</b>	
<b>SIMATIC WinCC flexible 2008 Micro incl. SP1</b> Single license, on DVD w/o license key, includes: <ul style="list-style-type: none"> <li>• Engineering software for configuring Micro Panels</li> </ul>	<b>6AV6610-0AA01-3CA8</b>
<b>SIMATIC WinCC flexible 2008 Compact incl. SP1</b> Floating license, on DVD incl. license key on USB stick, includes: <ul style="list-style-type: none"> <li>• Engineering software for configuring Micro Panels, Basic Panels and 70/170 series Panels incl. C7-635</li> </ul>	<b>6AV6611-0AA51-3CA5</b>
<b>SIMATIC WinCC flexible 2008 Standard incl. SP1</b> Floating license, on DVD incl. license key on USB stick, includes: <ul style="list-style-type: none"> <li>• Engineering software for configuring Micro Panels, Basic Panels and 70/170/270/370 series Panels incl. C7-635/636</li> </ul>	<b>6AV6612-0AA51-3CA5</b>
<b>SIMATIC WinCC flexible 2008 Advanced incl. SP1</b> Floating license, on DVD incl. license key on USB stick, includes: <ul style="list-style-type: none"> <li>• Engineering software for configuring WinCC flexible Runtime as well as Micro Panels, Basic Panels and 70/170/270/370 series Panels incl. C7-635/636</li> </ul>	<b>6AV6613-0AA51-3CA5</b>
<b>SIMATIC WinCC flexible 2008 ASIA Standard incl. SP1</b> Floating license, on DVD incl. license key on USB stick, includes: <ul style="list-style-type: none"> <li>• Engineering software for configuring Micro Panels, Basic Panels and 70/170/270/370 series Panels incl. C7-635/636</li> </ul>	<b>6AV6612-0AA11-3CA5</b>
<b>SIMATIC WinCC flexible 2008 ASIA Advanced incl. SP1</b> Floating license, on DVD incl. license key on USB stick, includes: <ul style="list-style-type: none"> <li>• Engineering software for configuring WinCC flexible Runtime as well as Micro Panels, Basic Panels and 70/170/270/370 series Panels incl. C7-635/636</li> </ul>	<b>6AV6613-0AA11-3CA5</b>
<b>SIMATIC WinCC flexible 2008 CHINA Standard incl. SP1</b> Single license, on DVD, includes: <ul style="list-style-type: none"> <li>• Engineering software for configuring Micro Panels (6), Basic Panels and 70/170/270/370 Series Panels incl. C7-635/636</li> </ul>	<b>6AV6612-0AA31-3CA8</b>
<b>Power Packs for WinCC flexible 2008 Engineering software</b> Floating license, license key on USB stick only: <ul style="list-style-type: none"> <li>• WinCC flexible 2008 Compact to WinCC flexible 2008 Standard</li> <li>• WinCC flexible 2008 Compact to WinCC flexible 2008 Advanced</li> <li>• WinCC flexible 2008 Standard to WinCC flexible 2008 Advanced</li> </ul>	<b>6AV6612-2BC01-3AD5</b> <b>6AV6613-2BD01-3AD5</b> <b>6AV6613-2CD01-3AD5</b>
<b>Options for WinCC flexible 2008 Engineering software</b> Floating license, license key on USB stick only: <ul style="list-style-type: none"> <li>• WinCC flexible /ChangeControl for WinCC flexible Compact, Standard, Advanced</li> </ul>	<b>6AV6613-6AA01-3AB5</b>
<b>Engineering software upgrades</b>	
<b>SIMATIC WinCC flexible 2004/2005/2007 to SIMATIC WinCC flexible 2008 incl. SP1</b> Floating License, on DVD incl. license key on USB stick, includes: <ul style="list-style-type: none"> <li>• WinCC flexible Micro</li> <li>• WinCC flexible Compact, incl. ChangeControl (upgrade)</li> <li>• WinCC flexible Standard, incl. ChangeControl (upgrade)</li> <li>• WinCC flexible Advanced, incl. ChangeControl (upgrade)</li> </ul>	<b>6AV6610-0AA01-3CE8</b> <b>6AV6611-0AA51-3CE5</b> <b>6AV6612-0AA51-3CE5</b> <b>6AV6613-0AA51-3CE5</b>
<b>SIMATIC WinCC flexible 2004/2005/2007 to SIMATIC WinCC flexible 2008 ASIA incl. SP1</b> Floating License, on DVD incl. license key on USB stick, includes: <ul style="list-style-type: none"> <li>• WinCC flexible ASIA Standard, incl. ChangeControl (upgrade)</li> </ul>	<b>6AV6612-0AA11-3CE5</b>



<ul style="list-style-type: none"> <li>· WinCC flexible ASIA Advanced, incl. ChangeControl (upgrade)</li> </ul>	<b>6AV6613-0AA11-3CE5</b>
<b>Service Pack 1 for WinCC flexible 2008 Engineeringsoftware und Runtime software</b> DVD containing the Service Pack 1 for WinCC flexible 2008	<b>S79220-B1580-P</b>
<b>Software Update Service for WinCC flexible Engineeringsoftware</b> <ul style="list-style-type: none"> <li>· WinCC flexible Compact</li> <li>· WinCC flexible Standard</li> <li>· WinCC flexible Advanced</li> </ul>	<b>6AV6611-0AA00-0AL0</b> <b>6AV6612-0AA00-0AL0</b> <b>6AV6613-0AA00-0AL0</b>
<b>SIMATIC ProTool to SIMATIC WinCC flexible 2008 incl. SP1</b> Floating License, on DVD incl. license key on USB stick, includes: <ul style="list-style-type: none"> <li>· ProTool/Lite to WinCC flexible Compact</li> <li>· ProTool to WinCC flexible Standard</li> <li>· ProTool/Pro CS to WinCC flexible Advanced</li> </ul>	<b>6AV6611-3AA51-3CE5</b> <b>6AV6612-3AA51-3CE5</b> <b>6AV6613-3AA51-3CE5</b>
<b>Configuration sets</b> <b>SIMATIC WinCC flexible 2008 incl. SP1,</b> <b>Configuration set for SIMATIC OP/TP 70 and OP/TP 170</b> Contains: <ul style="list-style-type: none"> <li>· Engineering software SIMATIC WinCC flexible Compact</li> <li>· SIMATIC HMI Manual Collection</li> <li>· RS 232 cable 5m</li> <li>· MPI cable 5m</li> <li>· PC/PPI cable RS232-RS485</li> </ul>	<b>6AV6621-0AA01-0AA0</b>
<b>SIMATIC WinCC flexible 2008 incl. SP1,</b> <b>Configuration set for SIMATIC OP/TP/MP 277, MP 377</b> Contains: <ul style="list-style-type: none"> <li>· Engineering software SIMATIC WinCC flexible Standard</li> <li>· SIMATIC HMI Manual Collection</li> <li>· RS 232 cable 5m</li> <li>· MPI cable 5m</li> <li>· PC/PPI cable RS232-RS485</li> </ul>	<b>6AV6622-0BA01-0AA0</b>
<b>Runtime software</b> <b>SIMATIC WinCC flexible 2008 Runtime incl. SP1</b> for PC systems; incl. SW for options for PC systems Single license, on DVD incl. license key on USB stick, includes: <ul style="list-style-type: none"> <li>· 128 PowerTags</li> <li>· 512 PowerTags</li> <li>· 2048 PowerTags</li> <li>· 4096 PowerTags</li> </ul>	<b>6AV6613-1BA51-3CA0</b> <b>6AV6613-1DA51-3CA0</b> <b>6AV6613-1FA51-3CA0</b> <b>6AV6613-1GA51-3CA0</b>
<b>Power Packs for WinCC flexible 2008</b> Single license, license key on USB stick only: <ul style="list-style-type: none"> <li>· 128 to 512 PowerTags</li> <li>· 128 to 2048 PowerTags</li> <li>· 512 to 2048 PowerTags</li> <li>· 128 to 4096 PowerTags</li> <li>· 512 to 4096 PowerTags</li> <li>· 2048 to 4096 PowerTags</li> </ul>	<b>6AV6613-4BD01-3AD0</b> <b>6AV6613-4BF01-3AD0</b> <b>6AV6613-4DF01-3AD0</b> <b>6AV6613-4BG01-3AD0</b> <b>6AV6613-4DG01-3AD0</b> <b>6AV6613-4FG01-3AD0</b>
<b>Runtime software upgrades</b> <b>SIMATIC WinCC flexible 2004/2005/2007 Runtime to WinCC flexible 2008 Runtime incl. SP1</b> for PC systems Single license, on CD-ROM, incl. upgrade license key on USB stick for WinCC flexible Runtime options: <ul style="list-style-type: none"> <li>· from WinCC flexible 2004/2005/2007 to WinCC flexible 2008 Runtime</li> </ul>	<b>6AV6613-1XA51-3CE0</b>
<b>SIMATIC WinCC flexible 2004/2005/2007 panel options to WinCC flexible 2008 panel options</b> for panels	



<p>Single license, license key on USB stick only:</p> <ul style="list-style-type: none"> <li>· from WinCC flexible 2004/2005/2007 to WinCC flexible 2008</li> </ul>	<b>6AV6618-7XX01-3AF0</b>
<p><b>SIMATIC ProTool/Pro RT to WinCC flexible 2008 Runtime incl. SP1</b> for PC systems</p> <p>Single License, on CD-ROM, incl. upgrade license key on USB stick for Runtime, Archives and Recipes:</p> <ul style="list-style-type: none"> <li>· from ProTool/Pro RT 128 to WinCC flexible 2008 Runtime 128 Powertags</li> <li>· from ProTool/Pro RT 256 to WinCC flexible 2008 Runtime 512 Powertags</li> <li>· from ProTool/Pro RT 512 to WinCC flexible 2008 Runtime 512 Powertags</li> <li>· from ProTool/Pro RT 2048 to WinCC flexible 2008 Runtime 2048 Powertags</li> </ul>	<b>6AV6613-3BB51-3CE0</b> <b>6AV6613-3CD51-3CE0</b> <b>6AV6613-3DD51-3CE0</b> <b>6AV6613-3FF51-3CE0</b>
<p><b>Runtime options</b></p> <p><b>Options for WinCC flexible 2008 Runtime software</b></p> <p>Single license, license key on USB stick only:</p> <ul style="list-style-type: none"> <li>· WinCC flexible /Sm@rtAccess for WinCC flexible Runtime</li> <li>· WinCC flexible /Sm@rtService for WinCC flexible Runtime</li> <li>· WinCC flexible /OPC-Server for WinCC flexible Runtime</li> <li>· WinCC flexible /ProAgent for WinCC flexible Runtime</li> <li>· WinCC flexible /Archives for WinCC flexible Runtime</li> <li>· WinCC flexible /Recipes for WinCC flexible Runtime</li> <li>· WinCC flexible /Archives+Recipes for WinCC flexible Runtime</li> <li>· WinCC flexible /Audit for WinCC flexible Runtime</li> </ul>	
<p><b>Options for SIMATIC Panels</b></p> <p>Single license, license key on USB stick only:</p> <ul style="list-style-type: none"> <li>· WinCC flexible /Sm@rtAccess for SIMATIC panel 177B/270/370 series</li> <li>· WinCC flexible /Sm@rtService for SIMATIC panel 177B/270/370 series</li> <li>· WinCC flexible /OPC-Server for SIMATIC Multi Panel</li> <li>· WinCC flexible /ProAgent for SIMATIC panel 270/370 series</li> <li>· WinCC flexible /Audit for SIMATIC panel 270/370 series</li> </ul>	<b>6AV6618-7AB01-3AB0</b> <b>6AV6618-7BB01-3AB0</b> <b>6AV6618-7CC01-3AB0</b> <b>6AV6618-7DB01-3AB0</b> <b>6AV6618-7HB01-3AB0</b>
<p><b>Introduction packages</b></p> <p><b>WinCC flexible 2008 incl. SP1, introduction package for SIMATIC Panel</b></p> <ul style="list-style-type: none"> <li>· WinCC flexible 2008 Standard incl. SP1</li> <li>· WinCC flexible Standard Software Update Service (voucher)</li> <li>· WinCC flexible /Sm@rtAccess für SIMATIC Panel</li> <li>· WinCC flexible /Sm@rtService für SIMATIC Panel</li> <li>· SIMATIC HMI Manual Collection</li> </ul>	<b>6AV6622-1AA01-0AA0</b>
<p><b>WinCC flexible 2008 incl. SP1, introduction package 128 PowerTags</b></p> <ul style="list-style-type: none"> <li>· WinCC flexible 2008 Advanced incl. SP1</li> <li>· WinCC flexible Advanced Software Update Service (voucher)</li> <li>· WinCC flexible 2008 Runtime, 128 PowerTags</li> <li>· WinCC flexible /Archives+Recipes für WinCC flexible Runtime</li> <li>· WinCC flexible /Sm@rtAccess für WinCC flexible Runtime</li> <li>· WinCC flexible /Sm@rtService für WinCC flexible Runtime</li> <li>· SIMATIC HMI Manual Collection</li> </ul>	<b>6AV6623-1BA01-0AA0</b>
<p><b>WinCC flexible 2008 incl. SP1, introduction package 512 PowerTags</b></p> <ul style="list-style-type: none"> <li>· WinCC flexible 2008 Advanced incl. SP1</li> <li>· WinCC flexible Advanced Software Update Service (voucher)</li> <li>· WinCC flexible 2008 Runtime, 512 PowerTags</li> <li>· WinCC flexible /Archives+Recipes für WinCC flexible Runtime</li> <li>· WinCC flexible /Sm@rtAccess für WinCC flexible Runtime</li> <li>· WinCC flexible /Sm@rtService für WinCC flexible Runtime</li> <li>· SIMATIC HMI Manual Collection</li> </ul>	<b>6AV6623-1DA01-0AA0</b>
<p><b>WinCC flexible 2008 incl. SP1, introduction package 2048 PowerTags</b></p> <ul style="list-style-type: none"> <li>· WinCC flexible 2008 Advanced incl. SP1</li> </ul>	<b>6AV6623-1FA01-0AA0</b>



<ul style="list-style-type: none"> <li>• WinCC flexible Advanced Software Update Service (voucher)</li> <li>• WinCC flexible 2008 Runtime, 2048 PowerTags</li> <li>• WinCC flexible /Archives+Recipes für WinCC flexible Runtime</li> <li>• WinCC flexible /Sm@rtAccess für WinCC flexible Runtime</li> <li>• WinCC flexible /Sm@rtService für WinCC flexible Runtime</li> <li>• SIMATIC HMI Manual Collection</li> </ul>	
<p><b>Documentation</b></p> <p><b>SIMATIC HMI Manual Collection 07/2008</b></p> <p>electronic documentation on DVD; 5 languages (German, English, French, Italian, Spanish); contains: all currently available user manuals, manuals and communication manuals for SIMATIC HMI</p> <p><b>User manual WinCC flexible Micro - 07/2008</b></p> <ul style="list-style-type: none"> <li>· German</li> <li>· English</li> <li>· French</li> <li>· Italian</li> <li>· Spanish</li> </ul>	<p><b>6AV6691-1SA01-0AX0</b></p> <p><b>6AV6691-1AA01-3AA0</b></p> <p><b>6AV6691-1AA01-3AB0</b></p> <p><b>6AV6691-1AA01-3AC0</b></p> <p><b>6AV6691-1AA01-3AD0</b></p> <p><b>6AV6691-1AA01-3AE0</b></p>
<p><b>User manual WinCC flexible Compact/Standard/Advanced - 07/2008</b></p> <ul style="list-style-type: none"> <li>· German</li> <li>· English</li> <li>· French</li> <li>· Italian</li> <li>· Spanish</li> </ul>	<p><b>6AV6691-1AB01-3AA0</b></p> <p><b>6AV6691-1AB01-3AB0</b></p> <p><b>6AV6691-1AB01-3AC0</b></p> <p><b>6AV6691-1AB01-3AD0</b></p> <p><b>6AV6691-1AB01-3AE0</b></p>
<p><b>User manual WinCC flexible Runtime - 07/2008</b></p> <ul style="list-style-type: none"> <li>· German</li> <li>· English</li> <li>· French</li> <li>· Italian</li> <li>· Spanish</li> </ul>	<p><b>6AV6691-1BA01-3AA0</b></p> <p><b>6AV6691-1BA01-3AB0</b></p> <p><b>6AV6691-1BA01-3AC0</b></p> <p><b>6AV6691-1BA01-3AD0</b></p> <p><b>6AV6691-1BA01-3AE0</b></p>
<p><b>User manual WinCC flexible Kommunikation - 07/2008</b></p> <ul style="list-style-type: none"> <li>· German</li> <li>· English</li> <li>· French</li> <li>· Italian</li> <li>· Spanish</li> </ul>	<p><b>6AV6691-1CA01-3AA0</b></p> <p><b>6AV6691-1CA01-3AB0</b></p> <p><b>6AV6691-1CA01-3AC0</b></p> <p><b>6AV6691-1CA01-3AD0</b></p> <p><b>6AV6691-1CA01-3AE0</b></p>

### [Upgrade da SIMATIC ProTool a SIMATIC WinCC flexible 2008](#)

Così come è stato per le versioni precedenti, il cliente può richiedere l'upgrade da ProTool a WinCC flexible 2008 a prezzo speciale! In fondo alla presente info è stato inserito il modulo di richiesta (**Modulo1**) da compilare ed inviare a casa madre allegando, come prova di acquisto, il certificato di licenza della versione completa di Protool di cui il cliente è in possesso oppure una copia della relativa fattura.

### [Upgrade da WinCC flexible Micro 2004/2005/2007 a SIMATIC WinCC flexible 2008 Micro](#)

Quanto sopra riportato per Protool è valido anche per WinCC Flexible Micro. I clienti che posseggono una versione WinCC flexible 2004/2005 o 2007 Micro possono richiedere l'upgrade a WinCC flexible 2008 Micro a prezzo speciale seguendo la stessa procedura sopra citata. Occorre compilarne il secondo modulo riportato in fondo alla presente info (**Modulo 2**).

### [Introduction Package e Starter Kit:](#)



### Introduction package WinCC Flexible 2008 per PC:

- WinCC Flexible 2008 Advanced
- Coupon per Software Update Service (validità: 1 anno)
- Opzione WinCC Flexible/ Archives
- Opzione WinCC Flexible/Recipes
- Opzione WinCC Flexible/ Sm@rtAccess
- Opzione WinCC Flexible/Sm@rtService
- CD ROM con documentazione
- Runtime software WinCC Flexible 2008 Runtime da:

**Risparmio del  
45% sui singoli  
articoli!**

128 Power Tags: codice 6AV6623-1BA01-0AA0  
512 Power Tags: codice 6AV6623-1DA01-0AA0  
2048 Power Tags: codice 6AV6623-1FA01-0AA0

### Introduction package WinCC Flexible 2008 per pannelli Simatic:

- WinCC Flexible 2008 Standard
- Coupon per software Update Service (validità:1 anno)
- Opzione WinCC Flexible/ Sm@artAccess
- Opzione WinCC Flexible/ Sm@artService
- CD ROM con documentazione

**Risparmio del  
35% sui singoli  
articoli!**

Codice 6AV6622-1AA01-0AA0

### Starter package per pannelli Simatic:

**Con gli starter package si risparmia tra  
il 20% ed il 45% sull'acquisto dei singoli articoli!**

Gli starter package contengono tutto ciò di cui si ha bisogno per cominciare a lavorare, ossia:

Pannello Operatore  
Software di progettazione  
Cavi (e connection box per i Mobile Panel) per collegamento e download  
Coupon per Software Update Service (validità:1 anno)  
Documentazione su CD

Gli starter Package sono disponibili per i seguenti pannelli:

1. **OP 73 micro** codice: \_\_\_\_\_ 6AV6 650 0BA01 0AA0
2. **TP 177 micro** codice: \_\_\_\_\_ 6AV6 650 0DA01 0AA0
3. **OP 73** codice: \_\_\_\_\_ 6AV6 651 1AA01 0AA0
4. **OP 77A** codice: \_\_\_\_\_ 6AV6 651 1BA01 0AA0
5. **OP 77B** codice: \_\_\_\_\_ 6AV6 651 1CA01 0AA0
6. **TP 177A** codice: \_\_\_\_\_ 6AV6 651 2AA01 0AA0
7. **TP 177B Col.** codice: \_\_\_\_\_ 6AV6 551 2EA01 1AA0
8. **OP 177B Col.** codice: \_\_\_\_\_ 6AV6 551 2HA01 1AA0
9. **TP 177B 4"** codice: \_\_\_\_\_ 6AV6 652-2KA00-0AA0



- 10. **MP 277 8" T.** codice: \_\_\_\_\_ 6AV6 652-3MB01-0AA0
- 11. **MP277 10" T.** codice: \_\_\_\_\_ 6AV6 652-3PB01-0AA0
- 12. **MP377 12" T.** codice: \_\_\_\_\_ 6AV6 652-4FA01-0AA0
- 13. **MP377 15"** codice: \_\_\_\_\_ 6AV6 652-4GA01-0AA0
- 14. **MobilePanel 177 DP Plus** codice: \_\_\_\_\_ 6AV6 6515BA01 0AA0
- 15. **MobilePanel 177 PN Plus** codice: \_\_\_\_\_ 6AV6 651 5DA01 0AA0
- 16. **MobilePanel 277 DP Plus** codice: \_\_\_\_\_ 6AV6 651-5EB01-0AA0
- 17. **MobilePanel 277 PN Plus** codice: \_\_\_\_\_ 6AV6 651-5FB01-0AA0
- 18. **Mobile Panel 277 IWLAN** codice: \_\_\_\_\_ 6AV6 651-5GA01-0AA0
- 19. **Mobile Panel 277(F) IWLAN** codice: \_\_\_\_\_ 6AV6 651-5HA01-0AA0

scopri tutte le novità del mondo SIMATIC su:

<http://www.siemens.it/automazione>

Modulo 1



**Automation and Drives**

Siemens AG  
A&D AS EWK PU2  
D-76185 Karlsruhe

Email: [hmi.migration.aud@siemens.com](mailto:hmi.migration.aud@siemens.com)  
Fax: +49 721 595 893 3523

## **Upgrade da Engineering Software ProTool a WinCC flexible 2008**

- da ProTool/Lite a WinCC flexible 2008 Compact**  
(6AV6611-3AA51-3CE5)
- da ProTool a WinCC flexible 2008 Standard**  
(6AV6612-3AA51-3CE5)
- da ProTool/Pro CS a WinCC flexible 2008 Advanced**  
(6AV6613-3AA51-3CE5)



**Estremi dell'Ordine (LIAZ):** \_\_\_\_\_

**Procedura per l'ordinazione:**

- Selezionare con una croce il prodotto da ordinare
- Inserire il LIAZ dell'ordine (chiedendolo eventualmente all'elaborazione ordini)
- Allegare al presente modulo una copia del certificato di licenza cartaceo di Protool o, in alternativa, una copia della bolla di acquisto di Protool e spedire via e\_mail o via FAX all'indirizzo sopra riportato.

**N.B.: L'ordine verrà evaso solamente se i dati verranno forniti secondo quanto indicato sopra .**

---

Indirizzo per la spedizione / Address

Modulo 2

**SIEMENS**

**Automation and Drives**

Siemens AG  
Postfach 70 04 0  
D-76185 Karlsruhe

Email: [hmi.migration.aud@siemens.com](mailto:hmi.migration.aud@siemens.com)  
Fax: +49 721 595 893 3523

**SIMATIC WinCC flexible 2008 Micro**  
**Upgrade da SIMATIC WinCC flexible 2004/2005/2007 Micro**  
**(6AV6610-0AA01-3CE8)**

**Estremi dell'Ordine (LIAZ):** \_\_\_\_\_

**Procedura per l'ordinazione:**



- Inserire il LIAZ dell'ordine (chiedendolo eventualmente all'elaborazione ordini)
- Allegare al presente modulo una copia del certificato di licenza cartaceo di WinCC Flexible Micro o, in alternativa, una copia della bolla di acquisto di WinCC Flexible Micro e spedire il tutto via e\_mail o via FAX all'indirizzo sopra riportato.

**N.B.: L'ordine verrà evaso solamente se i dati verranno forniti secondo quanto indicato sopra .**

---

Indirizzo per la spedizione /Address